
Measurement of Grating Structure Evolution Using Off-Normal Spectral Reflectometry

Brooke S. Stutzman, Wei Kong, Hsu-ting Huang, Hunsuk Kim and Fred L. Terry, Jr.

Applied Physics and the Department of Electrical Engineering and Computer Science

University of Michigan, Ann Arbor

Research funded in part by:

AFOSR/DARPA MURI Center for Intelligent Electronics Manufacturing
(AFOSR F49620-95-1-0524)

Semiconductor Research Corporation (Contract 97-FC085)



Outline

- Motivation
- Comparison of current techniques
- Off-Normal Spectral Reflectometry
- Experiments
- Conclusions
- Future work



Motivation

High speed *in situ* film thickness and surface topography measurement system

- Experimentally relate wafer data to plasma measurements
- Industrial process control


Current technology: Spectroscopic Ellipsometry (SE) with array detectors

- Expensive
- Slower



Off-Normal Spectral Reflectometry

$$\tan(\Psi) = \frac{|R_p|}{|R_s|} = \frac{\left| \frac{E_{rp}}{E_{ip}} \right|}{\left| \frac{E_{rs}}{E_{is}} \right|}$$




ONSR Vs SE

ONSR	SE
High Signal to Noise Ratio & Fast Sampling Times with Inexpensive Spectrometers	More Expensive Detectors Needed to Get Equivalent S/N Performance $\{\tan(\psi)\}$
More Than Half of SE Data $ R_p ^2, R_s ^2 \Rightarrow \tan(\psi)$	Both $\tan(\psi)$, and <u>Phase $\{\cos(\Delta)\}$</u>
No Moving Parts	Moving Parts, More Complex Electronics \Rightarrow More Likely to Break
Construction Cost \sim \$7K	Commercial Systems \sim \$100K
Need to Calibrate for Absolute Intensity	Insensitive to Absolute Intensity



GEC Reference Cell and ONSR



Calibration

$$R = \left(\frac{I_{meas} - I_{bkg}}{I_{ref} - I_{bkg}} \right) R_{th,ref}(\mathbf{I})$$

I_{meas} = measured intensity from sample


I_{bkg} = measured background intensity

I_{ref} = measured intensity from reference material

$R_{th,ref}(\mathbf{I})$ = theoretical reflectance from reference material



10058Å SiO₂ on Si




Fit comparison

ONSR Tan(ψ) Fit	SE α - β Fit	Difference
17883 Å	17931 Å	48 Å
10050 Å	10052 Å	2 Å
3932 Å	3939 Å	7 Å
494 Å	509 Å	15 Å




Real-Time Etch Monitoring: Blanket Film

- SiO₂ Etched in CF₄ at 50 & 100W
- Thickness from Fit to Both $|R_p|^2$ & $|R_s|^2$
- 6ms Integration Time, 1s Sampling Time
- Thickness Repeatability $\sigma_d = 0.22 \text{ \AA}$
- Etch Rate Standard Deviation $\sigma_e = 0.37 \text{ \AA/s}$




Submicron Grating




- 0.35 μm Line/Space Grating In Photoresist/300 \AA SiO_2/Si
- Period Measured as 0.700 μm Using 1st Order Diffraction Angle at Multiple λ 's
- Diffraction from Grating Yields Strong Structure-Related Features in Both $\tan(\psi)$ & $\cos(\Delta)$




Tan(γ) Vs wavelength, SE and ONSR



tan(γ) Vs wavelength



2mm PR grating evolution during etch



Conclusions

- More than half SE info
- Affordable
- Small
- Accurate
- High speeds possible
- No moving parts



Future Work

- RCWA method - detailed feature analysis
- Scalar reflection model - high speed analysis
- Correlate pattern evolution with plasma parameters
- Extend Instrument to Spectroscopic Ellipsometry Mode with 1/4 Wave Achromatic Compensator



Acknowledgements

The authors would like to thank T. Li, P. Klimecky, A. Salian, M. Gulari, D. Grimard, C. Galarza, C. Garvin and D. Schweiger for their help on this project.

